



Philips  
Portable Radio

**DAB+**  
Bluetooth®



**TAR5505**

## The kitchen radio

Whip up an omelette to your morning playlist. Prep dinner while you stream a podcast. With DAB+, FM, and Bluetooth, this portable radio brings your kitchen to life. Plus, the kitchen timer function ensures you'll get the recipe just right.

### Radio and more. Sounds to cook to.

- Beautiful design that fits right in
- Wooden cabinet with fabric speaker cover
- DAB+/FM radio. Digital tuning with up to 20 presets
- Bluetooth. Stream, music, podcasts, and more

### Easy listening

- Great in the kitchen
- 3" full-range speaker driver
- Clear display. Kitchen timer
- Buttons on the front for source, tuning, presets, and more

### At home with you

- Compact and convenient
- Mains (AC) or battery powered
- Dimensions: 206.6x140.6x106 mm
- Weight 0.86 kg

**PHILIPS**

# Specifications

## Tuner/Reception/Transmission

- Auto digital tuning
- Tuner bands: FM, DAB/DAB+
- DAB: info display, menu, smart scan
- Station presets: 20

## Sound

- Output power (RMS): 5W
- Volume control: rotary (digital)

## Bluetooth® wireless technology

- Profiles: A2DP, AVRCP
- Range: 10M (free space)
- Version: V5.0

## Convenience

- Backlight color: white
- Display type: LCD display

## Alarm

- Kitchen timer

## Power

- Power supply: 100-240VAC, 50/60Hz
- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 4

## Accessories

- Cables/Connection: AC-DC adapter
- Quick start guide

## Dimensions

- Product dimensions (W x H x D):  
206.6 x 140.6 x 106 mm
- Product weight: 0.86 kg
- Packaging dimensions (W x H x D):  
296 x 186 x 144 mm
- Weight incl. Packaging: 1.31 kg

# Highlights

## Great in the kitchen

From non-stop music to the latest news, this digital radio is your ticket to better listening while you cook! The DAB+ tuner delivers crystal-clear reception, and you can set up to 20 presets for your favorite stations.

## Clear display. Kitchen timer

See how long your dish has left to cook, at a glance. This portable radio boasts a kitchen timer, which is simple to set via the radio menu. The digital display shows a countdown timer in hours, minutes, and seconds.

## Beautiful design that fits in

A light wood cabinet surrounds the black gloss display panel and the speaker, which is covered in grey speaker fabric. There are buttons on the front of the radio for tuning, source selection, and more. Volume up/down is controlled via the sleek rotary dial.

## Compact and convenient

Using the plug socket for your food mixer? Keep the music going with batteries instead. When you're done whisking, plug the portable radio into a mains supply using the AC cable.



Issue date 2020-06-05

Version: 8.1.2

12 NC: 8670 001 66659  
EAN: 48 95229 10822 6

© 2020 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)